


VISTA-15

VISTA-15CN

Security System

Programming Guide



® ADEMCO

Local programming requires the use of a 2-line alpha keypad connected to the keypad terminals on the control.

Field Function [] = Default Value Programmed Values **Field Function [] = Default Value Programmed Values**

SYSTEM SETUP (*20 – *30)

<p>*20 INSTALLER CODE [] [] [] [] Enter 4 digits, 0–9 [4 1 1 2]</p> <p>*21 QUICK ARM ENABLE [0] <input type="checkbox"/> † 1 = enable; 0 = disable</p> <p>*22 RF SYSTEM [0] <input type="checkbox"/> † 0 = none; 1 = 5800 (5881/5882) 4 = 5800 w/ RF Jam Detection</p> <p>*23 FORCED BYPASS [0] <input type="checkbox"/> † 0 = none; 1 = bypass open zones 0 for UL installations.</p> <p>*24 RF HOUSE ID CODE [00] <input type="checkbox"/> [] 00 = disable all wireless keypad usage; 01–31 = using 5827, 5827BD, and 5804BD</p> <p>*25 WIRED ZONE EXPANSION [0] <input type="checkbox"/> † 0 = none; 1 = 4219; 2 = 4229; 3 = 4204</p> <p>*26 CHIME BY ZONE [0] <input type="checkbox"/> † 0 = no; 1 = yes (program zones to chime on zone list 3)</p>	<p>*27 X–10 HOUSE CODE [0] <input type="checkbox"/> 0 = A, 1 = B, 2 = C, 3 = D, 4 = E, 5 = F, 6 = G, 7 = H, 8 = I, 9 = J, # + 10 = K, # + 11 = L, # + 12 = M, # + 13 = N, # + 14 = O, # + 15 = P</p> <p>*28 PHONE MODULE ACCESS CODE [00] <input type="checkbox"/> [] 1st digit: enter 1–9; 2nd digit: enter # + 11 for *, or # + 12 for #. Entering "0" for either digit disables code.</p> <p>*29 OUTPUT TO LONG RANGE RADIO [0] <input type="checkbox"/> 0 = disable; enable = Trouble code 1–9, B (# + 11), C (# + 12), D (# + 13), E (# + 14), or F (# + 15). The 2nd digit of Trouble Dialer Report is automatically entered from field *60. 0 for UL installations.</p> <p>*30 HARDWIRE SHORT DETECTION [0] <input type="checkbox"/> † 1 = enable; 0 = disable</p>
---	--

ZONE SOUNDS AND TIMING (*31 – *39)

<p>*31 SINGLE ALARM SOUNDING/ZONE [0] <input type="checkbox"/> † 1 = yes; 0 = no; 0 for UL installations.</p> <p>*32 FIRE SOUNDER TIMEOUT [0] <input type="checkbox"/> † 0 = timeout; 1 = no timeout</p> <p>*33 ALARM BELL TIMEOUT [1] <input type="checkbox"/> † 0 = none; 1 = 4 min; 2 = 8 min; 3 = 12 min; 4 = 16 min; 1 (4 min.) minimum for UL.</p> <p>*34 EXIT DELAY (in seconds) [2] <input type="checkbox"/> † 0 = 30 4 = 120 1 = 45 5 = 180 2 = 60 6 = 240 3 = 90 60 sec max for UL installations. Due to the Exit Delay Restart feature, set for 30 seconds.</p>	<p>*35 ENTRY DELAY 1 (zone type 01) [1] <input type="checkbox"/> † 0 = 30; 1 = 45; 2 = 60; 3 = 90; 4 = 120; 5 = 180; 6 = 240. 45 sec max. for UL installations.</p> <p>*36 ENTRY DELAY 2 (zone type 02) [2] <input type="checkbox"/> † 0 = 30; 1 = 45; 2 = 60; 3 = 90; 4 = 120; 5 = 180; 6 = 240. 45 sec max. for UL installations.</p> <p>*37 AUDIBLE EXIT WARNING [1] <input type="checkbox"/> † 0 = no; 1 = yes</p> <p>*38 CONFIRMATION OF ARMING DING [0] <input type="checkbox"/> † 0 = no; 1 = yes (wired keypads and RF); 2 = yes, RF only</p> <p>*39 POWER UP IN PREVIOUS STATE [1] <input type="checkbox"/> † 0 = no; 1 = yes; 1 for UL installations.</p>
---	---

† Entry of a number other than the one specified will give unpredictable results.

DIALER PROGRAMMING (★40 – ★52)

In fields ★40, ★41, ★42, enter up to the number of digits shown. Do not fill unused spaces. Enter 0–9; # +11 for ★; # +12 for #; # +13 for a 2-second pause.

★40 PABX ACCESS CODE

Enter 6 digits. If fewer than 6 digits are entered, exit by pressing ★ (and press 41, if entering next field). To clear entries from field, press ★40★.

★41 PRIMARY PHONE NO.

Enter up to 20 digits; do not fill unused spaces. If fewer than 20 digits entered, exit by pressing ★ (and press 42, if entering next field). To clear entries from field, press ★41★.

★42 SECONDARY PHONE NO.

Enter up to 20 digits; Do not fill unused spaces. If fewer than 20 digits entered, exit by pressing ★ (and press 43, if entering next field). To clear entries from field, press ★42★.

★43 PRIMARY SUBSCRIBER ACCOUNT NUMBER

[15 15 15 15]

★44 SECONDARY SUBSCRIBER ACCOUNT NUMBER

For fields ★43 and ★44:

Enter 0–9; # +11 for B; # +12 for C; # +13 for D; # +14 for E; # +15 for F. Enter ★ as 4th digit, if 3+1 dialer reporting is to be used. If only 3 digits used, exit by pressing ★ (and press next field).

To clear entries from field, press ★43★ or ★44★.
Examples:

For Acct. **1234**, enter:

 1 2 3 4

For Acct. **B234**, enter:

 #+11 2 3 4

★45 PHONE SYSTEM SELECT

 [1] †

If Cent. Sta. *IS NOT* on a WATS line: 0 = Pulse Dial;
1 = Tone Dial; if Cent. Sta. *IS* on a WATS line: 2 = Pulse Dial ; 3 = Tone Dial.

★46 REPORT FORMAT

 [7] † [7] †

Primary Secondary

- 0** = 3+1, 4+1 ADEMCO L/S STANDARD
- 1** = 3+1, 4+1 RADIONICS STANDARD
- 2** = 4+2 ADEMCO L/S STANDARD
- 3** = 4+2 RADIONICS STANDARD
- 6 or undefined** = 4+2 ADEMCO EXPRESS
- 7** = ADEMCO CONTACT ID REPORTING
- 8** = 3+1, 4+1 ADEMCO L/S EXPANDED
- 9** = 3+1, 4+1 RADIONICS EXPANDED

★47 SPLIT/DUAL REPORTING

 [0]

0 = Disable (Backup report only)

TO PRIMARY PHONE No. TO SECONDARY PHONE No.

- | | |
|---------------------------------|------------------|
| 1 = Alarms, Restore, Cancel | Others |
| 2 = All except Open/Close, Test | Open/Close, Test |
| 3 = Alarms, Restore, Cancel | All |
| 4 = All except Open/Close, Test | All |
| 5 = All | All |

TO PRIMARY PHONE No. TO PAGING No. * (Secondary) †

- | | |
|---------------------------|---|
| 6 = All except Open/Close | Alarms, Open/Close, for users 5-25*, Troubles |
| 7 = All reports | Alarms, Troubles |
| 8 = All reports | Alarms, Open/Close, for users 5-25*, Troubles |
| 9 = All except Open/Close | Open/Close for users 5-25* |

* Will report users 5-16 and, if using wireless button-type devices, will report the zone number of the arm or disarm button (10-25). Open/Close for users 1-4 are not reported.

**See Installation Instructions for an explanation of the paging format.

★48 DIALER DLY (BURG/FIRE) (in sec) [10] †

0 = no; 1 = 15; 2 = 30; 3 = 45; 4 = 60; Burg/Fire
5 = 120. 0 for UL installations.

★49 PERIODIC TEST REPORT

 [0] †

0 = none; 1 = 24 hours; 2 = weekly; 3 = 30 days
(Enter Test Code in field ★64.)

★50 TEST REPORT OFFSET

 [2] †

0 = 24 hour; 1 = 6 hours; 2 = 12 hours; 3 = 18 hours (Time to 1st report from programming or downloading.)

★51 SESCOA/RADIONICS SELECT

 [0] †

0 = Radionics (0 – 9, B – F reporting); 1 = SESCOA (0 – 9 only reporting). Select 0 for all other formats.

★52 CANCEL VERIFY

 [1]

0 = no; 1 = yes

† Entry of a number other than the one specified will give unpredictable results.

★56 / ★58 ZONE ASSIGNMENT/ALARM REPORT CODES

This field is an interactive mode. Fill in the required data on the worksheet below (and on next page) and follow the programming procedure in the installation manual. Zone Types are shown on page 6 of this manual.

ZONES ON CONTROL:

See explanation of headings on next page →

ZONE RESPONSE DESCRIPTION	ZONE NO. (Zn)	ZONE TYPE (ZT)	ALARM RPT CODE (Hex) (RC)	INPUT TYPE (In)	TIME (RT)
Wired Zone 1†	0 1	[09]	[01] [00]	HW [1]	
Wired Zone 2	0 2	[01]	[01] [00]	HW [1]	
Wired Zone 3	0 3	[01]	[01] [00]	HW [1]	
Wired Zone 4	0 4	[03]	[01] [00]	HW [1]	
Wired Zone 5	0 5	[03]	[01] [00]	HW [1]	
Wired Zone 6	0 6	[03]	[01] [00]	HW [1]	

† Zone 1 can be used as a 2-wire Fire zone.

Expansion Module Suprvsn	0 9	[05]	[01] [00]	—	—
Duress	9 2	— —	[01] [00]	—	—
Keypad Panic (1 & ★)	9 5	[00]	[01] [00]	—	—
Keypad Panic (3 & #)	9 6	[00]	[01] [00]	—	—
Keypad Panic (★ & #)	9 9	[07]	[01] [00]	—	—

EXPANSION ZONES: Assign zone numbers (Zn) 10–17 to 4219/4229 Auxiliary Wired Loops A–H, if used.
RF zones can use zone numbers (Zn) 10–35

[ENTER FOR
RF ONLY]

ZONE DESCRIPTION	ZONE NO. (Zn)	ZONE TYPE (ZT)	ALARM RPT CODE (Hex) (RC)	INPUT TYPE (In)	LEARNED RF INPUT (L)
4219/4229 Loop A 1st Exp'n Zone	1 0	[00]	[01] [00]	[03]	[1]
or RF Zones B	1 1	[00]	[01] [00]	[03]	[1]
C	1 2	[00]	[01] [00]	[03]	[1]
D	1 3	[00]	[01] [00]	[03]	[1]
E	1 4	[00]	[01] [00]	[03]	[1]
F	1 5	[00]	[01] [00]	[03]	[1]
G	1 6	[00]	[01] [00]	[03]	[1]
H	1 7	[00]	[01] [00]	[03]	[1]
RF Zones	1 8	[00]	[01] [00]	[03]	[1]
	1 9	[00]	[01] [00]	[03]	[1]
	2 0	[00]	[01] [00]	[03]	[1]
	2 1	[00]	[01] [00]	[03]	[1]
	2 2	[00]	[01] [00]	[03]	[1]
	2 3	[00]	[01] [00]	[03]	[1]
	2 4	[00]	[01] [00]	[03]	[1]
	2 5	[00]	[01] [00]	[03]	[1]
	2 6	[00]	[01] [00]	[03]	[1]
	2 7	[00]	[01] [00]	[03]	[1]
	2 8	[00]	[01] [00]	[03]	[1]
	2 9	[00]	[01] [00]	[03]	[1]
	3 0	[00]	[01] [00]	[03]	[1]
	3 1	[00]	[01] [00]	[03]	[1]
	3 2	[00]	[01] [00]	[03]	[1]
	3 3	[00]	[01] [00]	[03]	[1]
	3 4	[00]	[01] [00]	[03]	[1]
	3 5	[00]	[01] [00]	[03]	[1]

EXPLANATION OF ZONE ASSIGNMENT TABLE HEADINGS

Zn = ZONE NO. Zone Nos. are from 01 to 06, 09 to 35, 92, 95, 96, 99. Some are pre-assigned.
 With Field *25 set for auxiliary wired loops (4219, or 4229), use Zone Nos. 10–17 for loops A–H.
 With Field *22 set for RF (5800), use Zone Nos. 10–35.

ZT = ZONE TYPE	00 = Not Used	05 = Trouble Day/Alarm Night	12 = 24-Hour Monitor
	01 = Entry/Exit #1	06 = 24-Hr Silent	20 = Arm–Stay
	02 = Entry/Exit #2	07 = 24-Hr Audible	21 = Arm–Away
	03 = Perimeter	08 = 24-Hr Aux	22 = Disarm
	04 = Interior Follower	09 = Fire	23 = No Alarm Response
		10 = Interior w/Delay	24 = Silent Burglary

DEFAULT VALUES

Zn: 01 02 03 04
ZT: [09] [01] [01] [03]
Zn: 05 06 99
ZT: [03] [03] [07]

RC = ALARM REPORT CODE Two Hex Digits. For each Hex Digit, enter: 00–09 for 0–9, 10 for A, 11 for B, 12 for C, 13 for D, 14 for E, 15 for F. If 00 is entered as the first digit, there will be no report for that zone.
 For contact ID reporting, this is an enabling code only. Enter any hex digit (other than 00) in the first pair of boxes. The second pair of boxes are ignored.

In = LOOP INPUT TYPE

HW: Hard Wire
 AW: Aux Wire (4219 or 4229)

Enter 2 for AW: Auxiliary wired
 Enter 3 for RF: Supervised RF
 Enter 4 for UR: Unsupervised RF
 Enter 5 for BR: Button Type RF

Hardwire zone input types are automatically assigned.

RT = RESPONSE TIME 0 = 10mSec; 1 = 350mSec; 2 = 700mSec. Default Values for zones 01 – 06 = 1 (350mSec)

L = LEARNED RF INPUT Used with 5800 RF Loop Input Devices. Record transmitter input number.

SYSTEM STATUS REPORT CODES (*59 – *68) †

TO PROGRAM SYSTEM STATUS & RESTORE REPORT CODES (*59– *76, & *89):

With a 3+1 or 4+1 Standard Format: Enter a code in the *first* box: 1–9, 0, B, C, D, E, or F. Enter #+10 for 0, #+11 for B, #+12 for C, #+13 for D, #+14 for E, #+15 for F.

A 0 (*not* #+10) in the *first* box will disable a report.

A 0 (*not* #+10) in the *second* box will result in automatic advance to the next field when programming.

With an Expanded or 4+2 Format: Enter codes in *both* boxes (1st and 2nd digits) for 1–9, 0, or B–F, as described above.

A 0 (*not* #+10) in the *second* box will eliminate the expanded message for that report.

A 0 (*not* #+10) in *both* boxes will disable the report.

With Ademco Contact ID Reporting: Enter any digit (other than 0) in the *first* box, to enable zone to report (entries in the *second* boxes will be ignored).

A 0 (*not* #+10) in the *first* box will disable the report.

Examples:

For Code **3** (single digit), enter:

For Code **3 2** (two digits), enter:

For Code **B 2** (Hexadecimal), enter:

- *59 EXIT ERROR REPORT CODE [0]
- *60 TROUBLE REPORT CODE [00]
- *61 BYPASS REPORT CODE [00]
- *62 AC LOSS REPORT CODE [00]
- *63 LOW BAT REPORT CODE [00]
- *64 TEST REPORT CODE [00]
- *65 OPEN REPORT CODE [0] †
- *66 ARM AWAY/STAY RPT CODE [00] ††
 AWAY STAY
 † 2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.
 †† 2nd digit is automatically sent as the user number if expanded or 4+2 reporting is selected.
- *67 RF XMTR LOW BAT REPORT CODE [00] □
- *68 CANCEL REPORT CODE [00]

RESTORE REPORT CODES (*70 – *76) †

- *70 ALARM RESTORE RPT CODE [0]
 2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in *56, if expanded or 4+2 reporting is selected.
- *71 TROUBLE RESTORE RPT CODE [00]
- *72 BYPASS RESTORE RPT CODE [00]

- *73 AC RESTORE RPT CODE [00]
- *74 LOW BAT RESTORE RPT CODE [00]
- *75 RF XMTR LO BAT RST RPT CODE [00]
- *76 TEST RESTORE RPT CODE [00]

DAYLIGHT SAVING TIME (*77 – *78)

- *77 DAYLIGHT SAVING TIME [4,10] †
 START/END MONTH
 0 = Disabled; 1 = Jan; 2 = Feb; 3 = Mar....
 10 = Oct; 11 = Nov; 12 = Dec.
 (Enter 0-9); #+10 = 10; #+11 = 11; #+12 = 12
- *78 DAYLIGHT SAVING TIME [1,5] †
 START/END WEEKEND
 0 = Disabled; 1 = First; 2 = Second; 3 = Third;
 4 = Fourth; 5 = Last; 6 = Next to Last;
 7 = Third to Last

DYNAMIC SIGNALING (*79)

- *79 DYNAMIC SIGNALING [0] †
 1st Entry 2nd Entry
 DS Delay DS Priority
 D S Delay; 0-15 times a 15-sec delay
 1 = 15 secs; 2 = 30 secs; 3 = 45 secs;
 4 = 60 secs...etc.
 0 = No delay. (Reports are sent to both the Primary Phone No. and LRR).
 For UL installations, set for 0 = No delay
- D S Priority; 0 = Send message to Primary Phone No. first;
 1 = Send message to LRR first.

† Entry of a number other than the one specified will give unpredictable results.

OUTPUT AND SYSTEM SETUP (*80 – *93)

- | | |
|---|--|
| *80 OUTPUT RELAYS AND POWERLINE CARRIER DEVICES | <i>Program only if Relays and/or Powerline Carrier devices are to be used. See page 9.</i> |
| *81 ZONE LISTS FOR OUTPUT DEVICES | |

- *82 CUSTOM ALPHA EDITING (Also entered from field *56) See procedure in instructions.

- *84 AUTO STAY ARMING [0]
 0 = no; 1 = yes

- *85 CROSS ZONE TIMER (in seconds) [0]
 0 = 30
 1 = 45
 2 = 60
 3 = 90
 4 = 120
 5 = 180
 6 = 240

NOTE: This field (*85) and Zone List 04 are not to be used in UL installations.

- *87 ALARM PAGER DELAY TIME [3]
 0 = none
 1 = 1 minute
 2 = 2 minutes
 3 = 3 minutes

- *88 PAGER CHARACTERS (16 digits as user decides)

 (See field *41 for programming instructions)

- *89 EVENT LOG 80% FULL RPT CODE [00]

- *90 EVENT LOGGING [3]
 0 = None; 1 = Alarm/Alarm Restore;
 2 = Trouble/Trouble Restore; 4 = Bypass/Bypass Restore; 8 = Open/Close.
Example: To select "Alarm/Alarm Restore" and "Open/Close," enter 9 (1 + 8); to select all, enter #+15.
Note: System messages are logged when any non-zero selection is made.

- *91 OPTION SELECTION (AAV) [8]
 0 = None;
 4 = AAV;
 8 = Enable Exit Delay Restart;
 12 = Both enabled.
 0 for UL installations.

- *92 PHONE LINE MONITOR ENABLE [0]
 0 = Not used
 1 = Keypad display when line is faulted
 2 = Keypad display plus keypad trouble sound
 3 = Same as "2," plus Device #2 STARTS. If armed, external sounder activates also.
Note: Device #2 must either be programmed to be STOPPED in field *80 or STOPPED by Code + # + 8 + 2.

- *93 SWINGER SUPPRESSION [0]
 0 = Unlimited; 1 - 15 = Number of Alarms
 (0 - 9; #+10 = 10; #+11 = 11; #+12 = 12;
 #+13 = 13; #+14 = 14; #+15 = 15)
 0 for UL installations.

DOWNLOAD INFORMATION (*94, *95)

*94 DOWNLOAD PHONE NO.

Enter up to 20 digits, 0–9; #+11 for *; #+12 for #; # + 13 for a pause. Do not fill unused spaces. If fewer than 16 digits entered, exit field by pressing * (and press 95, if entering next field). To clear entries from field, press *94*.

Note: In UL installations, downloading may only be performed if a technician is at the site.

*95 RING DET COUNT FOR DWNLDING [0]

0 = Disable Station Initiated Download; 1–14 = number of rings (1–9, # +10 =10, # +11 =11, # +12 =12, # +13 =13, # +14 =14); 15 = answering machine defeat (# +15 =15)

Note: Do not enter 0 if using 4285/4286 Voice Module.

***96** INITIALIZES DOWNLOAD ID, SUBSCRIBER ACCOUNT NO. FOR INITIAL DOWNLOAD: No data entry required.

***97** SETS ALL PROGRAM FIELDS TO DEFAULT VALUES: No data entry required.

EXITS (*98, *99)

***98** Exits programming mode and *prevents* re-entry by: Installer Code + 8+ 0 + 0. If *98 is used to exit programming mode, system must be powered down. Then power up, and press * and # within 50 seconds of power-up.

***99** Exits programming mode and *allows* re-entry by: Installer Code + 8 + 0 + 0 or: Power-up, then press * and # within 50 seconds of power-up.

OUTPUT RELAYS/POWERLINE CARRIER DEVICES WORKSHEET FOR *80 and *81.

Applicable only if Relays and/or Powerline Carrier devices are to be used.

***80 OUTPUT DEVICES** – This is an Interactive Menu mode. Fill in the required data on the worksheet below and follow the programming procedure in the installation manual as you enter the data in response to the displays and prompts that appear in sequence.

- Notes:**
1. For Relays, field *25 must be programmed for a 4229 (Relays 01 and 02), **OR** for a 4204 (Relays 01 to 04).
 2. For Powerline Carrier devices, field *27 must be programmed with a House Code.
 3. Tamper of expansion units cannot be used to operate devices.

DEVICE NUMBER	ACTION (A)	S T A R T = either or both-			S T O P = either or both-		X-10 SELECT
		EVENT (EV)	ZONE LIST (ZL)	ZONE TYPE SYST OP'N (ZT)	RESTORE OF ZONE LIST (ZL)	ZONE TYPE /SYST OP'N (ZT)	
OUTPUT RELAY OR P.L.C.D.* 01	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 02	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 03	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>
OUTPUT RELAY OR P.L.C.D.* 04	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/>

* P.L.C.D. = Powerline Carrier device (X-10).

Where:

X-10 SELECT = Powerline Carrier device

Enter 1 if Powerline Carrier device is being used; enter 0 if relay is being used.

A = DEVICE ACTION

0 = **No Response**; 1 = Close for 2 sec; 2 = Close and stay closed; 3 = Pulse on and off.

EV = EVENT

0 = Not used; 1 = Alarm; 2 = Fault; 3 = Trouble.

Z L = ZONE LIST

1, 2, or 3 (from Field *81) or 0 = Not Used.

"START" ZONE LIST: Upon alarm, fault, or trouble of ANY zone on this list, device action will START.

"STOP" RESTORE of ZONE LIST: Upon restore of ALL zones on this list, device action will STOP. It need not be same list as used for START.

NOTE: Do not use input type "BR" transmitters in a zone list to STOP a relay action, since these transmitters do not send restores.

ZT = ZONE TYPE/SYSTEM OPERATION

Choices for Zone Types are:

- | | |
|------------------------------|-----------------------|
| 00 = Not Used | 06 = 24-Hr Silent |
| 01 = Entry/Exit #1 | 07 = 24-Hr Audible |
| 02 = Entry/Exit #2 | 08 = 24-Hr Aux |
| 03 = Perimeter | 09 = Fire |
| 04 = Interior Follower | 10 = Interior w/Delay |
| 05 = Trouble Day/Alarm Night | 24 = Silent Burglary |

Note: Any zone in "ZT" going into alarm, fault, or trouble will actuate relay.
Any zone of that type that restores will stop relay action.

Choices for System Operation are:

- | | |
|-----------------------------|----------------------------|
| 20 = Arming–Stay | 39 = Any Fire Alarm |
| 21 = Arming–Away | 40 = Bypassing |
| 22 = Disarming (Code + OFF) | 41 = AC Power Failure |
| 31 = End of Exit Time | 42 = System Battery Low |
| 32 = Start of Entry Time | 43 = Communication Failure |
| 33 = Any Burglary Alarm | 52 = Kissoff |
| 36 = At Bell Timeout** | 58 = Duress |
| 38 = Chime | |

Note: In normal operation mode:
Code + # + 7 + N Key Entry starts Device N.
Code + # + 8 + N Key Entry stops Device N.

** Or at Disarming, whichever occurs first.

- *81 ZONE LISTS FOR OUTPUT DEVICES** (01 - 03); Cross Zones (04); and Night-Stay Zones (05). This is an interactive mode. Fill in the required data on the worksheet below and follow the procedure in the installation manual as you enter the data in response to the displays and prompts that appear in sequence.

Note: Record desired zone numbers below. More or fewer boxes than shown may be needed, since any list may include *any* or *all* of system's zone numbers.

Zone List 01: Started or stopped by zone numbers (enter 00 to end entries).

, , , , , , , , , ...etc.

Zone List 02: Started or stopped by zone numbers (enter 00 to end entries).

, , , , , , , , , ...etc.

Zone List 03: Started or stopped by zone numbers AND/OR assignment of Chime zones (enter 00 to end entries).

, , , , , , , , , ...etc.

Zone List 04: Cross Zone list: An alarm will occur if the system is armed and two or more of these active burglary zones (Entry/Exit 1 or 2, Interior Follower, Perimeter, Trouble Day/Alarm, Night, or Interior w/ Delay) remain faulted after Cross Zone time has expired, and this mode is enabled.

, , , , , , , , , ...etc.

NOTE: This Zone List 04 is not to be used in UL installations.

Zone List 05: Night Stay Zones: These interior zones (Interior Follower or Interior w/ delay) will be armed when arming the system in the Night-Stay mode.

, , , , , , , , ...etc.

NOTE: Zone 92, DURESS, must **not** be programmed into any Zone List.

SPECIAL MESSAGES

OC = OPEN CIRCUIT (no communication between console and control).

EE or **ENTRY ERROR** = ERROR (invalid field number entered; re-enter valid field number).

After powering up, "**AC, dl**" (disabled) or "**Busy Standby**" and "**NOT READY**" will be displayed after approximately 4 seconds. This will revert to **READY** in approximately 1 minute, which allows PIRS, etc. to stabilize.

To bypass this delay, press: # + 0.

If **E4** or **E8** appears, more zones than the expansion units can handle have been programmed. Correct the programming and then completely de-power and re-power the control to clear this indication and remove the disable indication.

TO ENTER PROGRAMMING MODE:

1. POWER UP, then press ★ and # both at once, within 50 seconds of powering up.
OR
2. Initially, key: **Installer Code (4 + 1 + 1 + 2)** plus **8 + 0 + 0**.
OR
3. If different **Installer Code** is programmed, key: **New Installer Code + 8 + 0 + 0**.
(If ★ 98 was used to exit previously, method 1 above must be used to enter the program mode again.)

TO EXIT PROGRAMMING MODE:

- ★98 Exits programming mode and *prevents* re-entry by keying Installer Code + 8 + 0 + 0. If ★98 is used to exit programming mode, system must be powered down, and method 1 above used to enter the programming mode.
- ★99 Exits programming mode and *allows* re-entry by keying Installer Code + 8 + 0 + 0; or by powering up, then pressing ★ and # within 50 seconds of power-up.

ALPHA VOCABULARY LIST

(For Entering Zone Descriptors)

000 (Word Space)	• 062 DRIVEWAY	• 113 LIVING	• 167 SERVICE	• 225 ZONE
A	• 064 DUCT	• 114 LOADING	• 168 SHED	• 226 0
• 001 AIR	E	115 LOCK	169 SHOCK	• 227 1
• 002 ALARM	• 065 EAST	116 LOOP	• 170 SHOP	• 228 1ST
004 ALLEY	066 ELECTRIC	117 LOW	171 SHORT	• 229 2
005 AMBUSH	067 EMERGENCY	• 118 LOWER	• 173 SIDE	• 230 2ND
• 006 AREA	068 ENTRY	M	174 SKYLIGHT	• 231 3
• 007 APARTMENT	• 069 EQUIPMENT	• 119 MACHINE	175 SLIDING	• 232 3RD
• 009 ATTIC	• 071 EXIT	121 MAIDS	• 176 SMOKE	• 233 4
010 AUDIO	• 072 EXTERIOR	122 MAIN	• 178 SONS	• 234 4TH
B	F	• 123 MASTER	• 179 SOUTH	• 235 5
• 012 BABY	• 073 FACTORY	• 125 MEDICAL	180 SPRINKLER	• 236 5TH
• 013 BACK	075 FAMILY	126 MEDICINE	• 182 STATION	• 237 6
• 014 BAR	• 076 FATHERS	128 MONEY	184 STORE	• 238 6TH
• 016 BASEMENT	• 077 FENCE	129 MONITOR	• 185 STORAGE	• 239 7
• 017 BATHROOM	• 079 FIRE	• 130 MOTHERS	186 STORY	• 240 7TH
• 018 BED	• 080 FLOOR	• 131 MOTION	190 SUPERVISED	• 241 8
• 019 BEDROOM	081 FLOW	132 MOTOR	191 SUPERVISION	• 242 8TH
020 BELL	082 FOIL	N	192 SWIMMING	• 243 9
• 021 BLOWER	• 083 FOYER	• 134 NORTH	193 SWITCH	• 244 9TH
• 022 BOILER	084 FREEZER	135 NURSERY	T	245 Custom Word #1
023 BOTTOM	• 085 FRONT	O	194 TAMPER	
025 BREAK	G	• 136 OFFICE	196 TELCO	246 Custom Word #2
• 026 BUILDING	• 089 GARAGE	• 138 OPEN	197 TELEPHONE	
C	• 090 GAS	139 OPENING	• 199 TEMPERATURE	
028 CABINET	091 GATE	• 140 OUTSIDE	200 THERMOSTAT	
• 029 CALL	• 092 GLASS	142 OVERHEAD	• 201 TOOL	247 Custom Word #3
030 CAMERA	093 GUEST	P	202 TRANSMITTER	
031 CAR	094 GUN	143 PAINTING	U	
033 CASH	H	• 144 PANIC	• 205 UP	248 Custom Word #4
034 CCTV	• 095 HALL	145 PASSIVE	• 206 UPPER	
035 CEILING	• 096 HEAT	• 146 PATIO	• 207 UPSTAIRS	
036 CELLAR	098 HOLDUP	147 PERIMETER	• 208 UTILITY	249 Custom Word #5
• 037 CENTRAL	099 HOUSE	• 148 PHONE	V	
038 CIRCUIT	I	150 POINT	209 VALVE	
• 040 CLOSED	100 INFRARED	151 POLICE	210 VAULT	250 Custom Word #6
• 046 COMPUTER	• 101 INSIDE	152 POOL	212 VOLTAGE	
047 CONTACT	102 INTERIOR	• 153 POWER	W	
D	103 INTRUSION	R	213 WALL	251 Custom Word #7
• 048 DAUGHTERS	J	155 RADIO	214 WAREHOUSE	
049 DELAYED	104 JEWELRY	• 156 REAR	• 216 WEST	252 Custom Word #8
• 050 DEN	K	157 RECREATION	• 217 WINDOW	
051 DESK	• 105 KITCHEN	159 REFRIGERATION	• 219 WING	
• 052 DETECTOR	L	160 RF	220 WIRELESS	253 Custom Word #9
• 053 DINING	• 106 LAUNDRY	• 161 RIGHT	X	
054 DISCRIMINATOR	• 107 LEFT	• 162 ROOM	222 XMITTER	
055 DISPLAY	108 LEVEL	163 ROOF	Y	254 Custom Word #10
• 057 DOOR	• 109 LIBRARY	S	223 YARD	
• 059 DOWN	• 110 LIGHT	164 SAFE	Z	
• 060 DOWNSTAIRS	111 LINE	165 SCREEN	224 ZONE (No.)	
061 DRAWER		166 SENSOR		

NOTE: Bulleted (•) words in **boldface type** are those that are also available for use by the 4285/4286 VIP Module. If you are using a phone module, and words other than these are selected for alpha descriptors, the phone module will not provide annunciation of those words.

CHARACTER (ASCII) CHART



(For Adding Custom Words)

32 (space)	39 '	46 .	53 5	60 <	67 C	74 J	81 Q	88 X
33 !	40 (47 /	54 6	61 =	68 D	75 K	82 R	89 Y
34 "	41)	48 0	55 7	62 >	69 E	76 L	83 S	90 Z
35 #	42 *	49 1	56 8	63 ?	70 F	77 M	84 T	
36 \$	43 +	50 2	57 9	64 @	71 G	78 N	85 U	
37 %	44 ,	51 3	58 :	65 A	72 H	79 O	86 V	
38 &	45 -	52 4	59 ;	66 B	73 I	80 P	87 W	


[illegible]

24 HR BATTERY STANDBY REQUIRED FOR FIRE INSTALLATIONS. USE 12V, 17.2AH BATTERY FOR 500mA AUX POWER. SEE INSTRUCTIONS. BATTERY STANDBY TIME FOR EMERGENCY BURGLARY MUST BE AT LEAST 4 HOURS.

SEALED LEAD ACID TYPE BATTERY NORMALLY NEED NOT BE REPLACED FOR AT LEAST 3 YRS. TO DETERMINE TOTAL STANDBY LOAD ON BATTERY, ADD 100mA TO TOTAL OF AUX. POWER




OPTIONAL ZONES (ONE FROM EITHER OR BOTH GROUPS)



SET UNIT'S DIP SWITCH FOR DEVICE ADDRESS OF "1". SEE INSTRUCTIONS.

SET RECEIVER'S DIP SWITCH FOR DEVICE ADDRESS OF "0". SEE INSTRUCTIONS.



USE UL LISTED LIMITED ENERGY CABLE FOR ALL CONNECTIONS

PLUG-IN TRANSFORMER 16.5VAC, 25VA (e.g. ADEMCO No. 1321, USE No. 1321CN IN CANADA)

USE 4300 TRANSFORMER INTERFACE IN PLACE OF 1321 WHEN POWER LINE CARRIER DEVICES ARE BEING USED (SEE INSTRUCTIONS FOR CONNECTIONS)

ALARM OUTPUT
10.5-13.8VDC, 2A MAX. (600mA MAX. FOR UL USAGE, INCLUDING AUX POWER)

STEADY FOR BURGLARY/PANIC, TEMPORAL PULSE SOUNDING FOR FIRE (e.g. USE ADEMCO No. 702 SIREN, OR 12V BELL). SEE INSTRUCTIONS. DRAIN CALCULATIONS.

CONNECT 2k RESISTOR ACROSS LAST SOUNDING DEVICE FOR BELL SUPERVISION


AUX. POWER OUTPUT
10.5-13.8VDC 600mA MAX. (500mA MAX. FOR UL INSTALLATIONS) INTERRUPTS FOR 4-WIRE FIRE ALARM RESET. ALL CIRCUITS ARE POWER LIMITED.

NOTE: KEYPAD(S) CURRENT AND ALL OTHER DEVICES DRAWING POWER FROM TERMS 4 & 5 MUST BE INCLUDED IN AUX CURRENT DRAIN CALCULATIONS.

BLACK: KEYPAD GROUND (-) RETURN
RED: KEYPAD PWR (+)
GREEN: DATA IN FROM KEYPAD
YELLOW: KEYPAD DATA OUT

REMOTE KEYPAD
USE 6148 OR 6160 KEYPADS. LOCAL PROGRAMMING MUST BE DONE WITH A 6160 CONNECTED TO KEYPAD TERMINALS, BUT NEED NOT REMAIN IN THE SYSTEM.

CAN BE USED FOR 2-WIRE SMOKE DETECTORS



OPTIONAL:
5800TM TRANSMITTER MODULE (20mA) (for 5827BD Wireless Bidirectional Console) AND/OR 4285/4286 VOICE MODULE (160mA) AND/OR ECP Compatible LONG RANGE RADIO MAY ALSO BE CONNECTED. SEE INSTRUCTIONS ACCOMPANYING THOSE DEVICES.

MAXIMUM LOOP RESISTANCE: (EACH ZONE) 300 OHMS (PLUS EOLR)

RESPONSE, ZONES 1-6: 10, 350, OR 700 MSEC (PROGRAMMABLE)

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION. ANY

COMPLIES WITH FCC RULES, PART 68. FCC REGISTRATION NO. AC398U-68192-AL-E RINGER EQUIVALENCE: 0.7B.

FOR COMPLETE INFORMATION SEE INSTRUCTIONS ACCOMPANYING VISTA-15 CONTROL (K3892)

WARNING: TO PREVENT RISK OF SHOCK, DISCONNECT TELEPHONE LINE AT TELCO JACK BEFORE SERVICING THIS UNIT.

THIS EQUIPMENT SHOULD BE INSTALLED IN ACCORDANCE WITH THE NATIONAL FIRE PROTECTION ASSOCIATION'S STANDARD 72, CHAPTER 2 (NATIONAL FIRE PROTECTION ASSOC., BATTERYMARCH PARK, QUINCY, MA 02269). PRINTED INFORMATION DESCRIBING PROPER INSTALLATION, OPERATION, TESTING, MAINTENANCE, EVACUATION PLANNING AND REPAIR SERVICE IS TO BE PROVIDED WITH THIS EQUIPMENT.

WEEKLY TESTING IS REQUIRED TO ENSURE PROPER OPERATION OF THIS SYSTEM.

VISTA-15/VISTA-15CN SUMMARY OF CONNECTIONS

ADEMCO **GROUP**

165 Eileen Way, Syosset, New York 11791
Copyright © 2000 PITTWAY CORPORATION



K3894V2 7/01 (See Instructions K3892V2)